

```
1 -----
2 --
3 --          GNAT RAVENSCAR for NXT          --
4 --          Copyright (C) 2010-2012, AdaCore --
5 --
6 -----
7
8 -- Low-level I/O driver for the AVR.
9
10 with Interfaces; use Interfaces;
11
12 package NXT.AVR_IO is
13
14     -----
15     -- Outgoing --
16     -----
17
18     procedure Send_Initialization;
19     -- send the mandatory initialization message to the AVR
20
21     type Outgoing_AVR_Message is private;
22     -- Represents all messages sent to the AVR
23
24     Null_Outgoing_Msg : constant Outgoing_AVR_Message;
25
26     function Power_Down_Message return Outgoing_AVR_Message;
27
28     function Set_Sensor_Power_Message
29         (Port      : Sensor_Id;
30          Power_Type : Sensor_Power)
31         return Outgoing_AVR_Message;
32
33     function Set_Motor_Message
34         (Motor : Motor_Id;
35          Power : PWM_Value;
36          Brake : Boolean)
37         return Outgoing_AVR_Message;
38
39     procedure Send_To_AVR (This : Outgoing_AVR_Message);
40     -- computes and appends checksum, sends to AVR
```

```
41
42  -----
43  -- Incoming --
44  -----
45
46  type Incoming_AVR_Message is private;
47  -- Represents all messages received from the AVR
48
49  type Raw_ADC_Inputs is array (Sensor_Id) of Unsigned_16;
50  pragma Atomic_Components (Raw_ADC_Inputs);
51  -- A/D converter values, each with a range of 0 .. 1023
52
53  function Raw_Inputs (From : Incoming_AVR_Message) return Raw_ADC_Inputs;
54  -- Returns the raw input readings from the message. Does no actual
55  -- "decoding", just provides access.
56  pragma Inline_Always (Raw_Inputs); -- just an accessor function
57
58  function Buttons_Sample (From : Incoming_AVR_Message) return Unsigned_16;
59  -- Returns the raw buttons reading contained within From
60  pragma Inline_Always (Buttons_Sample); -- just an accessor function
61
62  function Battery_Reading (From : Incoming_AVR_Message) return Unsigned_16;
63  -- Returns the battery reading contained within From
64  pragma Inline_Always (Battery_Reading); -- just an accessor function
65
66  procedure Receive_From_AVR
67  (This : out Incoming_AVR_Message;
68   Valid : out Boolean);
69  -- Receives the next message from the AVR and places into This iff the
70  -- checksum in the received message is correct. If the checksum is not
71  -- correct, no update to This takes place.
72  -- On return, Valid will be True if checksum in received message is
73  -- correct, otherwise it will be False.
74
75 private
76
77  -- outgoing message representation, sent from ARM to AVR
78
79  type PWM_Output_Values is array (0 .. 3) of PWM_Value;
80  for PWM_Output_Values'Component_Size use 8;
```

```
81   for PWM_Output_Values'Size use 32; -- confirming
82
83   type Port_Bits is array (Sensor_Id) of Boolean;
84   for Port_Bits'Component_Size use 1;
85   for Port_Bits'Size use 4; -- confirming
86
87   type Sensor_Power_Control is
88     record
89       Pulsed_9V   : Port_Bits; -- "active"
90       Constant_9V : Port_Bits;
91     end record;
92
93   for Sensor_Power_Control use
94     record
95       Pulsed_9V   at 0 range 0 .. 3;
96       Constant_9V at 0 range 4 .. 7;
97     end record;
98
99   for Sensor_Power_Control'Size use 8; -- confirming
100
101   type Motor_Braking_Control is (No_Braking, Braking);
102   for Motor_Braking_Control use (No_Braking => 0, Braking => 1);
103   -- the above is confirming, but the values are essential so we make it
104   -- explicit to prevent accidental reordering later
105
106   type Motor_Braking_Modes is array (0 .. 7) of Motor_Braking_Control;
107   -- bit 0 is Motor A, 1 is Motor B, and 2 is Motor C; others are unused
108   for Motor_Braking_Modes'Component_Size use 1;
109   for Motor_Braking_Modes'Size use 8; -- confirming
110
111   type Outgoing_AVR_Message is
112     record
113       Power_Command : Unsigned_8;
114       PWM_Frequency : Unsigned_8; -- in KHz units, range 1 .. 32
115       PWM_Values    : PWM_Output_Values;
116       Output_Mode   : Motor_Braking_Modes;
117       Input_Power   : Sensor_Power_Control;
118       Checksum      : Unsigned_8;
119     end record;
120
```

```
121   for Outgoing_AVR_Message use
122     record
123       Power_Command at 0 range 0 .. 7;
124       PWM_Frequency at 1 range 0 .. 7;
125       PWM_Values    at 2 range 0 .. 31;
126       Output_Mode   at 6 range 0 .. 7;
127       Input_Power   at 7 range 0 .. 7;
128       Checksum      at 8 range 0 .. 7;
129     end record;
130
131   Null_Outgoing_Msg : constant Outgoing_AVR_Message :=
132     (Power_Command => 0,
133      PWM_Frequency => 0,
134      PWM_Values    => (0, 0, 0, 0),
135      Output_Mode   => (others => No_Braking),
136      Input_Power   => ((others => False), (others => False)),
137      Checksum      => 0);
138
139   -- incoming message representation, received from AVR
140
141   type Incoming_AVR_Message is
142     record
143       Inputs    : Raw_ADC_Inputs; -- Raw a/d converter values [0..1023]
144       Buttons   : Unsigned_16;    -- Raw a/d converter values [0..1023]
145       Battery   : Unsigned_16;    -- Raw a/d converter values [0..1023]
146       Checksum  : Unsigned_8;
147     end record;
148
149   for Incoming_AVR_Message use
150     record
151       Inputs    at 0 range 0 .. 63;
152       Buttons   at 8 range 0 .. 15;
153       Battery   at 10 range 0 .. 15; -- also contains firmware info
154       Checksum  at 12 range 0 .. 7;
155     end record;
156
157 end NXT.AVR_IO;
```

158